
FORSTER PRODUCTS

310 E. LANARK AVENUE, LANARK, ILLINOIS 61046 PHONE 815-493-6360 (FAX 815-493-2371)

www.forsterproducts.com

CASE GRAPHITER INSTRUCTIONS



Fasten the base of the Graphiter to a loading bench or block of wood for stability. Level off graphite powder in the base of the Case Graphiter. Slide the empty case up and down on the proper-sized brush (the three brushes will accommodate all popular calibers). This cleans and lubricates the case neck. Replace the cover when the Graphiter is not in use. Wipe the white mica (graphite) off the outside diameter of the case necks to prevent scratching during the sizing process.

**Thank you for purchasing a Forster Precision Product. Please wear safety glasses.
Forster Catalogs are available upon request.**

011341-001 Rev. 1